

## ECIO2 Modbus table

8 DI, 8 DO, 8 AI, 6 AO Release 23.9.2011 ver. 00200



- max 27 words may be read out as a whole (i.e. 54 bytes)
- first 256 bits can be addressed bitwise (i.e. 1 LSB – 16 MSB)

Name	Address	Type	Description	Note
module ID LSB	1 LSB	R	module identification lower byte	module ID is 2101hex
module ID MSB	1 MSB	R	module identification upper byte	
firmware	2 LSB 2 MSB	R	NEC processor FW version	2hex
status LSB	3 LSB	R, W RAM	module status lower byte <b>bit 0</b> - EEPROM write enable <b>bit 4</b> - EEPROM init <b>bit 5</b> - calibration offset <b>bit 6</b> - calibration span <b>bit 7</b> - calibration enable	<b>EEPROM init</b> is enabled when the INIT switch was ON at power-up, and switched OFF before bit 4 was set to 1 (indicated by bit 2 in status MSB) <b>calibration</b> is enabled when the INIT switch was ON at power-up, and switched OFF before bit 7 was set to 1 (indicated by bit 3 in status MSB) <b>calibration offset</b> change bit 7 from 1 to 0 and set bit 5 to 1 <b>calibration span</b> change bit 7 from 1 to 0 and set bit 6 to 1
status MSB	3 MSB	R	module status upper byte <b>bit 0</b> - 0 normal mode - 1 init mode <b>bit 1</b> - 1 at the next EEPROM write attempt all data will be saved to EEPROM - 0 at the next write attempt received data will be written to RAM only <b>bit 2</b> - 1 - EEPROM initialised <b>bit 3</b> - 1 - calibration enabled <b>bit 4</b> - 0 <b>bit 5</b> - 1 <b>bit 6</b> - 0 <b>bit 7</b> - 1	
firmware 2	4 LSB 4 MSB	R	LPC processor (Ethernet interface)	0x01hex

## ECIO2 Modbus table

8 DI, 8 DO, 8 AI, 6 AO Release 23.9.2011 ver. 00200

**domat**  
control system

input range for AI1, AI2	5 LSB	R,W EEPROM	<b>1 ...Pt1000</b> (-50 to 150 °C) (-5000 to 15000), <b>divide by 100</b> to get the correct value <b>2 ... voltage 0V ... 10 V</b> (0 to 10000), <b>divide by 1000</b> to get the correct value <b>3 ... resistance 0 ... 1600 ohm</b> (0 to 16000), <b>divide by 10</b> to get the correct value <b>4 ... current 0 ... 20 mA</b> (0 to 20000), <b>divide by 1000</b> to get the correct value (NB. this range applies only for AI1 to AI4, the switch at the respective input must be set to ON.) <b>5 ... resistance 0 – 5000 ohm</b> (0 to 50000), <b>divide by 10</b> to get the correct value.	bit 0 – bit 3... channel 1 bit 4 – bit 7... channel 2 bit 0 – bit 3... channel 3 bit 4 – bit 7... channel 4 bit 0 – bit 3... channel 5 bit 4 – bit 7... channel 6 bit 0 – bit 3... channel 7 bit 4 – bit 7... channel 8
input range for AI3, AI4	5 MSB	R,W EEPROM		
input range for AI5, AI6	6 LSB	R,W EEPROM		
input range for AI7, AI8	6 MSB	R,W EEPROM		
latch state	7 LSB	R,W EEPROM	state to be latched <b>0</b> – log. 0 <b>1</b> – log. 1	
relay com	7 MSB	R,W EEPROM	<b>0</b> – when no communication, relays stay in last state <b>1</b> – when no communication, relays are set to <b>relay state</b> values	bit 0 is relay 1 ... bit 7 is relay 8
relay state	8 LSB	R,W EEPROM	relays go on or off (according to corresponding bits) if there was no communication with module for a given time and in <b>relay com</b> the corresponding relay bit is set to 1	bit 0 is relay 1 ... bit 7 is relay 8
relay time	8 MSB	R,W EEPROM	time in [s] of no communication which is considered as communication failure	if set to 0, the function is disabled
relay start enable	9 LSB	R,W EEPROM	startup relay behaviour <b>0</b> – relays are not commanded <b>1</b> – the corresponding relay is set to its <b>relay start</b> value after module startup	bit 0 is relay 1 ... bit 7 is relay 8
relay start	9 MSB	R,W EEPROM	relay status between power-up and first bus command	bit 0 is relay 1 ... bit 7 is relay 8

## ECIO2 Modbus table

8 DI, 8 DO, 8 AI, 6 AO Release 23.9.2011 ver. 00200

**domat**  
control system

<b>relay</b>	10 LSB	R, W RAM	commands to control relay outputs (DO1-DO8)	bit 0 is relay 1 ... bit 7 is relay 8
latch enable	10 MSB	R,W RAM	latch function enable for each input – if set to <b>1</b> the <b>latched value</b> bit goes to 0 and stays so until the latched value is detected; after RESET the register is set to 0	reset the <b>latched value</b> register bits to 0 by changing the value of <b>latch enable</b> bits from 0 to 1 (= disable and enable latching for individual bits)
<b>analogue outputs AO1</b>	11 LSB	R,W RAM	the AO values are ranged 0000 <sub>hex</sub> – 0FFF <sub>hex</sub> which is (0 dec – 4095 <sub>dec</sub> )  0000 <sub>hex</sub> is for 0V 0FFF <sub>hex</sub> is for 10V	analogue output channels
	11 MSB	R,W RAM		
<b>analogue outputs AO2</b>	12 LSB	R,W RAM		
	12 MSB	R,W RAM		
<b>analogue outputs AO3</b>	13 LSB	R,W RAM		
	13 MSB	R,W RAM		
<b>analogue outputs AO4</b>	14 LSB	R,W RAM		
	14 MSB	R,W RAM		
<b>analogue outputs AO5</b>	15 LSB	R,W RAM		
	15 MSB	R,W RAM		
<b>analogue outputs AO6</b>	16 LSB	R,W RAM		
	16 MSB	R,W RAM		
<b>inputs</b>	17 LSB	R	readout of binary inputs (DI1-DI8)	bit 0 is input 1 ... bit 7 is input 8
latched value	17 MSB	R	atched values <b>0</b> – if since latch enable the latched state has not been detected at the input <b>1</b> - if since latch enable the latched state has been detected at the input	reset of individual bits: disable and enable the corresponding bits – see register <b>latch enable</b>
<b>channel value AI1</b>	18 LSB	R	measured values at analogue inputs; scaling: see <b>input ranges</b> registers (regs. 5 to 6)	readouts of analogue inputs AI1..AI8
	18 MSB	R		
<b>channel value AI2</b>	19 LSB	R		
	19 MSB	R		
<b>channel value AI3</b>	20 LSB	R		
	20 MSB	R		
<b>channel value AI4</b>	21 LSB	R		
	21 MSB	R		
<b>channel value AI5</b>	22 LSB	R		
	22 MSB	R		
<b>channel value AI6</b>	23 LSB	R		
	23 MSB	R		
<b>channel value AI7</b>	24 LSB	R		
	24 MSB	R		

## ECIO2 Modbus table

8 DI, 8 DO, 8 AI, 6 AO Release 23.9.2011 ver. 00200

**domat**  
control system

<b>channel value AI8</b>	25 LSB	R		
	25 MSB	R		
uptime	26 LSB 27 MSB	R	uptime [s]	